

HENDERSON MANUFACTURING COMPANY

P.O. Box 1249, 80 County Road 4310, Pittsburg, TX 75686

Phone: 903-856-3658


Fax: 903-856-5602

www.hendersonmfgco.com


NEW QUICK CHANGE RAKE



FOR ALL CRAWLER TRACTORS
SWING-TYPE — SWINGS OUT WHEN YOU BACK UP
MADE FROM HEAT TREATED ALLOY STEEL CASTING



FOR
HEAVY DUTY
RAKING
OF TIMBER
AND ROCK



Rake is installed and held by two pins and brackets which are installed on the top end of moleboard of blade.

All thrust is against cutting edge.

May be assembled by your own shop. Simply cut two pieces of heavy angle to length of blade. Space teeth and weld on angle as required.

Braces and gussets are cast on the teeth, no cutting required.





HENDERSON MANUFACTURING COMPANY

P.O. Box 1249, 80 County Road 4310, Pittsburg, TX 75686
Phone: 903-856-3658 Fax: 903-856-5602

www.hendersonmfgco.com




TYPICAL SIDE VIEW



DIFFERENT SIZE ANGLE
IRON ONLY APPLIES
TO #65 RAKES

SIDE VIEW FOR
LONG TOOTH RAKE



RAKE TEETH ASSEMBLY